

Installation Instructions for the 7" Shelf

Tools and Materials Required:

- Torpedo Level
- Caulk Gun
- Hot Glue Gun
- Silicone 100% (to be used with Caulk Gun)
- Hot melt glue (to be used with Hot Glue Gun)
- Denatured Alcohol
- Pencil/Marker



1. Use denatured alcohol to clean the surface of the wall and the desired placement of the shelf. DO NOT clean this product with any abrasive material or cleanser. (i.e., steel wool, Comet, Ajax, Soft Scrub, etc.). These abrasives will dull the lustrous finish.
2. Using a leveler, draw a short line to mark where the shelf will be installed.
3. Prepare a hot glue gun, and a caulking gun with 100% silicone.
4. Measure the leveling support rod to fit the corner shelf. If needed, cut one of the support rods to the appropriate length to ensure it will be concealed.
5. Apply a thin line of hot glue on the back of the support rod. Then, attach it to the line you previously marked. Repeat this process for the second support rod.
6. Apply a thin line of silicone around the perimeter of the back side of the shelf. Be mindful of the amount used in order to ensure the silicone will not spread beyond the edges on the wall.
7. In order to attach the shelf to the wall instantly, apply a line of hot glue across the middle section of the shelf. Only use enough to ensure the shelf will stick to the wall.
8. Attach the adhesive side of the shelf to the wall.
9. Once the shelf is placed on the wall, finish applying silicone around the edges of the shelf. Using denatured alcohol, clean off any excess silicone around the edges of the shelf and wall.
10. For precautionary purposes, apply masking tape over the shelf and attach it to the walls to hold it in place.